

## wireless macacl modify

Modify an existing ACL entry.

### SYNTAX:

```
wireless macacl modify hwaddr = <hardware-address>
                        [permission = <{allow | deny}>]
                        [name = <quoted string>]
```

where:

hwaddr	The Ethernet MAC address of the ACL entry. <b>Note</b> If the MAC address is not present in the ACL list, the command will not be executed.	REQUIRED
permission	The action to be performed on ACL entry. Choose between: ▶ <b>allow</b> : the wireless client is allowed entry. ▶ <b>deny</b> : the wireless client is not allowed entry.	OPTIONAL
name	The name of the wireless client.	OPTIONAL

### EXAMPLE:

```
=>wireless macacl list
Station Name      hardware address  Permission
ST120g            00:02:2d:5f:b6:9e  accept
Test2             01:67:d0:23:56:cd  deny
=>wireless macacl modify hwaddr=01:67:d0:23:56:cd permission=allow name=Test3
=>wireless macacl list
Station Name      hardware address  Permission
ST120g            00:02:2d:5f:b6:9e  accept
Test3             01:67:d0:23:56:cd  accept
=>
```